



TARA PAINTS & CHEMICALS

Factory: A-423/14, Mahagujarat Ind.Estate, Sarkhej-Bavla Rd, Moraiya,
Dist-Ahmedabad, GUJARAT – 382210

Tel: (F): 02717-251256, 320003

Fax: 02717-251256

E-mail: taralac@hotmail.com

WEB: www.taralac.com

Taralac NC Wood Filler

Application & Surface Prepration

- Sand the wooden surfaces along the grains with Emery paper no. 100 or 180 wipe the surface to clean of loose dust particles.
- This should be followed by smooth sanding with emery paper no. 320 or 400 and clean of the surface to remove dust.
- Apply stains if required.
- Stir well the Taralac Clear Wood Filler and apply by using either a muslin cloth pad in circular motion or by using Putty knife, along the grains so that the grains/pores get filled. Remove the excess filler from the surface.
- Allow the wood filler to dry for 1 hour. Sand the surface with Emery paper no. 180 followed by Emery paper no. 320 or 400.
- Repeat the above procedure if required, so that the grains are filled completely. After drying, sand the surface with Emery paper no. 180 to remove excess of wood filler from the surface.
- Smooth sand the surface with Emery paper no. 320 or 400.

Precautions

Ensure that the wood filler fills the grains. Excess wood filler from the surface should be removed immediately while applying and also by sanding otherwise it will show patchiness after application of topcoats.

For effective filling at pores fill the mix of saw dust along with wood filler.